

# ROSALIND

## SOLAR FLOOR LAMP

# USER GUIDE



Ensure your solar panel is South facing or as near as possible



Clean your solar panel from time to time



Do NOT place your solar panel in shaded areas.



Do NOT charge behind glass

**Thank you for choosing the Rosalind Solar Floor Lamp. Please read these instructions carefully before using your light.**

### Important notes

Always take care when installing your light. If you are at all unsure, please contact your retailer or a professional trades person for advice.

### Installation

Remove all packaging and put to one side. Please carefully consider where you wish to install your light before making alterations to your property. It's particularly important that the solar panel receives as much sunlight as possible. Ensure that it is not obstructed by buildings, fences, trees, sheds, etc, or the shadows that these create. **If the solar panel is installed in a poor location, it may not perform to the best of its ability.**


To maximise the battery capacity, the lights should be charged in direct sunlight for at least 8 hours before being used for the first time.

The lights will turn ON/OFF automatically when left in the on position. Please note it is completely normal for the lights to come on at different times as it depends on how fast they charge in their location.

### Items Supplied

- 1 x Solar lamp
- 1 x Remote control with 1 x 3 V button cell (CR2025), already inserted
- 1 x Instructions

### Overview Remote




1. **OFF** button
2. **ON** button
3. **FLASH** (Flash function RGB + W + mixed colours)
4. **STROBE** (flash function RGB)
5. **FADE** (smooth change of colour RGB)
6. **SMOOTH** (colour gradient RGB + W + mixed colours)
7. Control pad for colour selection (12 mixed colours)
8. Setting RGB + W (Red, Green, Blue, White)
9. Brightness setting

### Changing the remote control battery



The battery is pre-installed. Only the transportation protection needs to be removed. Before inserting the battery, check whether it is clean and clean it if necessary.



1. The battery compartment is located on the narrow side of the remote control. Remove it as shown.
2. Remove the empty battery and insert a new battery (3 V, type CR2025). The positive terminal must point upwards.
3. Slide the battery compartment all the way back into the remote control, it must audibly and noticeably lock into place.

## Set-up

The solar lamp should not be placed near to other light sources such as street lamps or other lamps, so that the LEDs can be switched on automatically.

## Use



- The remote control only functions when the On/Off switch on the bottom of the solar lamp is pressed.
- The individual colours and modes can also be set by repeatedly pressing the On/Off switch (16 colours - modes).

**1. Activation** - To switch the solar lamp on, press the On/Off switch on the bottom for approx. 3 seconds.

The battery can now charge up in daylight. When darkness sets in, the LEDs automatically switch on. When it gets light, the LEDs switch off and the battery is charged up via the solar field.

**Please note:** Battery power can be severely impacted by extremely low temperatures.

**2. Selecting a colour** - Press the corresponding colour selection button (7,9) on the remote control or press the On/Off switch on the solar lamp several times to switch between the different colours.

**3. Setting the mode** - Press the corresponding mode button (3-6) on the remote control or press the On/Off switch on the solar lamp several times to switch between the different modes.

**4. Setting the brightness** - Set the brightness via the  and the  button (9).

**5. Turning LEDs on/off** - To turn the LEDs on or off, press the ON (2) or OFF button (1) on the remote control.

**Please note:** The solar lamp remains in stand-by, so that the storage battery can continue to charge during daylight.

**6. Deactivation** - To switch the solar lamp off, hold down the On/Off switch on the bottom for approx. 3 seconds.

## Troubleshooting

Please ensure that there are no nearby light sources shining on the solar panel after dark. These could be bright indoor/outdoor lights from your property or neighbours, or streetlights.

If you are unsure, take the light inside and test it in a dark room.

If you are encountering any problems with your light often you can resolve this yourself by following our troubleshooting guide. If the light has its solar panel in a poor location it will struggle to work, but that doesn't mean there is a fault with the unit. Please remember that the light will arrive with some charge and will likely work for a few days even if the solar panel is poorly located. Please try the troubleshooting tips below before contacting your retailer.

## Recharge Procedure

1. Double check the location of your solar panel to ensure it is in a clear location and as South facing as possible.
2. Turn the light off at the switch and leave it to recharge for 3-5 days ensuring one sunny day has passed.
3. After 3-5 days return to the light and turn it back on at the switch.
4. If your light still does not illuminate after dark, please contact your retailer.

## Safety Instructions

The Solar Centre assumes no liability for any damage resulting from the use of this product, nor do we assume liability for any damage to property or personal injury caused by improper use or failure to observe these instructions.

Unauthorised conversion and/or modification of the unit may be dangerous and will invalidate your warranty. To avoid damage to sight, do not look directly at the light source. This device is not a toy and should be kept out of reach of children. Do not submerge the device in water or expose it to extreme temperatures (less than -25°C or higher than 50°C).

For customer support please contact:

The Solar Centre Ltd  
44-46 Coldharbour Lane  
Harpenden  
Hertfordshire  
AL5 4UN

T: 01727 743200  
W: [solarcentre.co.uk](http://solarcentre.co.uk)  
E: [info@solarcentre.co.uk](mailto:info@solarcentre.co.uk)

