

WARWICK

SOLAR WALL LIGHT WITH MOTION

USER GUIDE



Ensure your solar panel is South facing or as near as possible



Clean your solar panel from time to time



Do NOT place your solar panel in shaded areas.



Do NOT charge behind glass

Thank you for choosing the Warwick Wall Light. Please read these instructions carefully before using your light.

Always take care when installing your light, especially when mounting it in high places. If you are at all unsure, please contact your retailer or a professional trades person for advice.

Please carefully consider where you wish to install your light before making alterations to your property. It's particularly important that the solar panel receives as much sunlight as possible. Ensure that it is not obstructed by buildings, fences, trees, sheds, etc, or the shadows that these create. If the solar panel is installed in a poor location, it may not perform to the best of its ability.

The motion sensor will detect up to 8m with a 90 degree detection angle, however this can vary depending on the location, positioning and other external factors such as temperature. The light will illuminate for up to 25seconds each time it detects motion.

Installation Instructions

1. Place the installation template onto the wall in your desired location.
2. Drill a hole into the wall using the template as a guide.
3. Place the wall plug provided into the drilled hole.
4. Drill your screw into the wallplug in the wall.
5. Place your wall light onto the wall.

How to use:

For best performance, please charge your solar light in the sun for a minimum of 8 hours before you switch it on for the first time.

Press and hold for 3 seconds to turn ON/OFF
To switch between the different modes, short press for 1 second

Mode A: Light is set to remain at low brightness

Mode B: Light is set to remain at low brightness until motion is detected which activates mid brightness for up to 25 seconds

Mode C: Light is only set to activate when motion is detected **[This is the best mode for Winter]**

Troubleshooting




Please ensure that there are no nearby light sources shining on the solar panel or motion sensor after dark. These could be bright indoor/outdoor lights from your property or neighbours, or streetlights.

If you are unsure, remove the light from it's wall bracket and take the light inside and test it in a dark room indoors.




If you are encountering any problems with your Warwick Light, often you can resolve this yourself by following our troubleshooting guide. If the Warwick has it's solar panel in a poor location it will struggle to work, but that doesn't mean there is a fault with the unit. Please remember that your light will arrive with some charge and will likely work for a few days even if the solar panel is poorly located. Please try the troubleshooting tips below before contacting your retailer:

Recharge Procedure

1. Double check the location of your solar panel to ensure it is in a clear location and as South facing as possible.
2. Turn your light off at the switch on the back of the light and leave it to recharge for 3-5 days ensuring one sunny day has passed.
3. After 3-5 days return to the light and turn it back on at the switch.
4. If your light still does not illuminate after dark, please contact your retailer.



1. Press for 3sec 2. Press for 1sec



For customer support please contact:

The Solar Centre Ltd
 44-46 Coldharbour Lane
 Harpenden
 Hertfordshire
 AL5 4UN

W: solarcentre.co.uk
 E: support@solarcentre.co.uk

