

Zeus Solar Spotlight

PLEASE CHARGE YOUR
LIGHT FOR 3 DAYS
BEFORE FIRST USE



Ensure your solar panel is South facing or as near as possible



Clean your solar panel from time to time



Do **NOT** place your solar panel in shaded areas.



Do **NOT** charge behind glass

User Guide

Thank you for choosing The Solar Centre's Zeus Solar Spotlight. Please read these instructions carefully before using your light.

How it Works:

In the daytime the solar panel absorbs sunlight which charges the batteries. At night, with the switch on the back of the light set to on, the light will turn on automatically at dusk and turn off automatically at dawn. With the switch set to off the unit will not operate.

Installing Your Light:

When positioning your light think about trying to avoid locations where sunlight reaching the solar panel is obstructed by trees, foliage, buildings, fences or the shadows these create. A sunny south facing location for the solar panel is always ideal.

Stake / Spike Installation

1. Attach ground pole to ground spike by pushing together
2. Push spike tip fully into the ground
3. Connect ground stake adapter to top of pole.
4. Connect light head to ground stake adapter
- 5a. Connect solar panel to top of light head by pushing together (option 1)
- 5b. Connect solar panel to separate ground stake by pushing together (option 2)
6. Remove and discard the protective film covering the solar panel.

Positioning the Solar Panel

A southerly facing position is best to maximise solar energy gain. The light may not perform satisfactorily if positioned to the north of a property.

Please ensure direct light can get to the panel as this may vary from season to season.

Changing the Batteries:

The batteries should last for up to 2 years.

- 1: Unscrew the lens from the front of the light
- 2: Gently tip forward allowing the light to slide out onto a surface.
- 3: Remove batteries from cradle and replace

Troubleshooting:

1: The light is dim or flashes

Batteries are not fully charged or may need replacing.

The solar panel needs bright light to recharge the batteries. Consecutive days of overcast weather may cause the batteries to lose power. If this happens the solar panel will recharge the batteries on the next bright day.

Check your solar panel is in an area where it gets the maximum amount of direct light every day.

Check for things obstructing light reaching the solar panel like over hanging branches, fences or buildings. If there are obstructions move the unit to a location that receives better light throughout the day.

Check the solar panel is clean. A dirty solar panel will not let the batteries charge fully. This will shorten the life of the batteries and stop the light operating. Clean the solar panel regularly with a damp cloth.

2: The light won't turn on

Check for an external light source like a street light or porch light, this may be stopping the light sensor from knowing when it is dark. Move the panel away from the external light source.

Rechargeable batteries may need charging, overcast weather could have prevented the batteries from recharging. Check to see if it works after the next sunny day.

Recharge Procedure

Please follow the recharge procedure if the batteries in your Zeus Solar Spotlight run flat. Please turn off your Zeus Solar Spotlight using the switch on the rear of the light and place it outside in a sunlit location for 5 days to gain a base charge. Ensure that the light hitting the solar panel is not obstructed in anyway. This is particularly important in winter when the days are shorter and the sun is lower in the sky and less powerful. Please note that your Zeus Solar Spotlight will not charge behind glass.

www.thesolarcentre.co.uk



Made in China to Solar Centre Specification

